

Connecting an Mprox Mini reader to Net2

Overview

MODE - The Brown wire controls the output format.

0V / Black Terminal = Clock and Data

Not connected = Wiegand Data

WIEGAND - The Yellow wire controls the number of bits output

0V / Black Terminal = 26 bit Wiegand Data


Not connected = 30 bit Wiegand Data

Further information on use and programming is available at:

<http://www.merlingo.org/files/accesscontrol/MPROXMINInst01.pdf>



Cable Pinout	ACU terminal
Red	+12V
Orange	Red LED
-	Amber LED
Blue	Green LED
Green	Wiegand D0
White	Wiegand D1
-	NOT USED
Black/Brown	0V



Ensure any unused wires are safely terminated.

To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.



+44 (0)1273 811011
support@paxton.co.uk
paxton.support



+49 (0) 251 2080 6900
support@paxton-gmbh.de
paxton.gmbh.support



+33 (0)157 329356
support@paxtonaccess.fr
paxton.support



+32 (0)78485147
support@paxton-benelux.com
paxton.benelux.support



+31 (0)76 3333 999
support@paxton-benelux.com
paxton.benelux.support



+27 (0)21 4276691
support@paxtonaccess.co.za
paxton.support



+1 (800) 672-7298
supportUS@paxton-access.com
usapaxton.support



+11 5715088198
soporte@paxton-access.com
paxton.soporte



+1 (864) 751-3501
soporte@paxton-access.com
paxton.soporte



8000 3570 3783
support@paxtonaccess.ae
paxton.support



+44 (0)1273 811011
support@paxton.co.uk
paxton.support