

## Sensor QR Code Reader


### Overview

The reader was tested by being wired into the Net2 plus reader 2 port on Net2 6.06.12017 using QR codes.

There is no LED response from the reader, the Red, White and Green LEDs remain static ON.



| Cable Pinout | ACU terminal |
|--------------|--------------|
| VCC          | +12V         |
| -            | Red LED      |
| -            | Amber LED    |
| -            | Green LED    |
| D0           | Wiegand D0   |
| D1           | Wiegand D1   |
| -            | NOT USED     |
| GND          | 0V           |



Ensure any unused wires are safely terminated.

For more information visit the manufacturers website:  
<https://www.sensoraccess.co.uk/>

Datasheet:  
<http://public.sensoraccess.co.uk/Products/Readers/Special/QRCode%2CORProx%20Datasheet.pdf>



+44 (0)1273 811011

support@paxton.co.uk

paxton.support



+49 (0) 251 2080 6900

support@paxton-gmbh.de

paxton.gmbh.support



+33 (0)157 329356

support@paxtonaccess.fr

paxton.support



+32 (0)78485147

support@paxton-benelux.com

paxton.benelux.support



+31 (0)76 3333 999

support@paxton-benelux.com

paxton.benelux.support



+27 (0)21 4276691

support@paxtonaccess.co.za

paxton.support



+1(800) 672-7298

supportUS@paxton-access.com

usapaxton.support



+11 5715088198

soporte@paxton-access.com

paxton.soporte



+1 (864) 751-3501

soporte@paxton-access.com

paxton.soporte



8000 3570 3783

support@paxtonaccess.ae

paxton.support



+44 (0)1273 811011

support@paxton.co.uk

paxton.support