

Connecting a Third Millenium TM4 reader to Net2

Overview

The TM4 can be configured to read a variety of different token types, and to output a variety of different data formats. The configuration performed during manufacture, and the full part number of the unit will indicate the configuration type. If this is unknown, contact Third Millenium to confirm these details, as they will affect the how the Net2 software is configured.



Cable Pinout	ACU terminal
Terminal 1	+12V
Terminal 5	Red LED
-	Amber LED
Terminal 4	Green LED
Terminal 3	Wiegand D0
Terminal 2	Wiegand D1
-	NOT USED
Terminal 7	0V

10	Red 12V dc	Reader 1
10	Red LED	
10	Amber LED	
10	Green LED	
10	Data/D0	
10	Clock/D1	
10	Media Detect	
10	0V out	

Ensure any unused wires are safely terminated.



+44 (0)1273 811011
support@paxton.co.uk
paxton.support



+49 (0) 251 2080 6900
support@paxton-gmbh.de
paxton.gmbh.support



+33 (0)157 329356
support@paxtonaccess.fr
paxton.support



+32 (0)78485147
support@paxton-benelux.com
paxton.benelux.support



+31 (0)76 3333 999
support@paxton-benelux.com
paxton.benelux.support



+27 (0)21 4276691
support@paxtonaccess.co.za
paxton.support



+1 (800) 672-7298
supportUS@paxton-access.com
usapaxton.support



+11 5715088198
soporte@paxton-access.com
paxton.soporte



+1 (864) 751-3501
soporte@paxton-access.com
paxton.soporte



8000 3570 3783
support@paxtonaccess.ae
paxton.support



+44 (0)1273 811011
support@paxton.co.uk
paxton.support