

Connecting a PHG RELINO 100 LEGIC Panel Mount reader to Net2

Overview

The unit tested was configured to read LEGIC cards to produce a Clock and Data output.



	Cable Pinout	ACU terminal
7	Red	+12V
2	Brown	Red LED
-	-	Amber LED
1	Green	Green LED
4	Yellow	Wiegand D0
3	Blue	Wiegand D1
5	-	NOT USED
6	Black	0V

10	Red 12V dc	Reader 1
10	Red LED	
10	Amber LED	
10	Green LED	
10	Data/D0	
10	Clock/D1	
10	Media Detect	
10	0V out	
10		

Ensure any unused wires are safely terminated.

To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.

Further information on use and programming is available at:

<http://www.phg.de/fileadmin/pdf/datentechnik/PHG-04-RELINO-150.pdf>



+44 (0)1273 811011
support@paxton.co.uk
paxton.support



+49 (0) 251 2080 6900
support@paxton-gmbh.de
paxton.gmbh.support



+33 (0)157 329356
support@paxtonaccess.fr
paxton.support



+32 (0)78485147
support@paxton-benelux.com
paxton.benelux.support



+31 (0)76 3333 999
support@paxton-benelux.com
paxton.benelux.support



+27 (0)21 4276691
support@paxtonaccess.co.za
paxton.support



+1 (800) 672-7298
supportUS@paxton-access.com
usapaxton.support



+11 5715088198
soporte@paxton-access.com
paxton.soporte



+1 (864) 751-3501
soporte@paxton-access.com
paxton.soporte



8000 3570 3783
support@paxtonaccess.ae
paxton.support



+44 (0)1273 811011
support@paxton.co.uk
paxton.support